

## ET80-W Fingerprint Time Attendance with WIFI


### Quick Start manual

#### 1. Switch to WIFI working Model

ET-WF09 support Wired LAN and Wifi work model, but the both model can not work at the same time, if you use it as wired lan type , please refer to other ET series manual, the operation is the same.

Now the following step is for Wifi working Model Setting

**Switch on the wifi model first**, see the back of the device, there is rubber cover, open it, you will find a switch as following picture:



As above, the other plug of the RJ45 cable you can insert it to HUB, router, which PC can access also, or insert the PC you are using.

What we should take care of, first the Wifi setting IP address is **fixed IP: 192.168.2.1**, then the setting of gateway in router or pc should be 192.168.2.\*. otherwise the 192.168.2.1 it may not available to get from your PC.

For example, the PC's IP config:




## 2. Setting the Connection of wifi

Power on device by press the power key in keypad of the device, then **power off the device** by press the power key, but don't unplug the power cable. Because the wifi module need power


Open a web browser, type ip :192.168.2.1

**The user name is admin, password is admin: please remember your Password if you change it, otherwise there is no solution to help you to solve it**




Then you open a page like this

You select the language here  
Chinese,English, Korea, Japanese




3. Wifi Config and User password

Click the LAN menu, and you can input the SSID manually, and select or input other box manually, or search wifi ssid by the search ap button.




Now I use search



Select the SSID you want to connect , Then click connect button, it will adjust input box and fill some box for you automatically, the only thing left to do is the add password



Please click apply button after you input password. It will give you page as following




Click return button

If above info you input have no problem, the setting is ok

By the way, how to change the password:

Click Admin → Click Password Submenu



Please Note: please don't change other setting of the wifi module, if you don't know its meaning or how to use it.

And in the module status menu page, you may see the wifi is disconnected, it doesn't matter, because wifi connection require you to power on the device

#### 4. Connection WIFI and connect Device by PC

Press Power key to power on the device, and disconnect the RJ45 cable

Press Menu key to enter Menu setting,

Menu → Set COMM → Ethernet

Set IP Address, Subnet mask, gateway, port No. etc as normal device

Remember the IP config you input should compatible with the WIFI network you connect.

Exit menu

For example the IP is input is 192.168.1.224

And now you can use it as a wired type device , other steps is the same as wired type device.

Thanks for your choice of ET-WF09 mode wifi type fingerprint time attendance device